

DYNACUTTER

Parts list

Code

Ball bearing	0601
Base screws (4)	9014
Coupling + pin	9051
Upper shaft assembly	9055
Complete adaptor	9070
Cover	9071
Knife assembly	9072
Dynacutter Bowl	9073
Knife cone support	9074
Inner assembly + ball bearing	9075
Bowl pivot	9076
Handle	9077
Handle screws	9078
Adaptator + seal + sticker	9080
Output shaft w/ gear	9081
Middle gear + shaft	9082
Complete adaptor base	9083
Axle 8x40	089948
Inferior blade	089949
Inferior serrated blade	089949D
Superior blade	089950
Superior serrated blade	089950D



